


ChinaCNCzone

Steel structure HY3040 5Axis USB Mach3 router machine Manual

Gross weight: 230KG





Content

- 1.....cable connection**
- 2Mach3 installation and setting**
- 3.....Machine calibration**
- 4.....Start point setting**
- 5.....Hand wheel installation**
- 6.....Mach3 Common tips**

Note : The dial gauges, special 5axis fixture, dial Gauge and handwheel that appear in the manual are all optional. If necessary, please contact sales to purchase.

1.connect as picture shown






2.Mach3 Installation


MACH3 was machine control software , The machine also need G code design software , We would try to provide fusion 360 G code design software in future. But we are able to provide post processor for G code design .

(Notice: Before installing, please turn off anti-virus software.)

1.Open the Compressed file, and find the file Mach3 soft . Open it And click the Mach3Eng and install the software.







2. Return to this interface, and find the file named “中文资料”， open it, open file “XHC-MKX-V”， right click “一键安装驱动”， Run as administrator.

名称	修改日期	类型	大小
English manual	2019/5/10 17:52	文件夹	
MACH3 Soft	2019/5/10 17:52	文件夹	
中文资料	2019/5/10 17:52	文件夹	
Mach1Lic.dat	2008/8/25 12:13	DAT 文件	1 KB

名称	修改日期	类型	大小
How to do Slave home	2018/6/11 13:41	DOCX 文档	120 KB
m200.m1s	2017/7/4 13:24	M1S 文件	1 KB
m201.m1s	2017/7/4 13:25	M1S 文件	1 KB
m202.m1s	2017/7/20 10:18	M1S 文件	1 KB
m203.m1s	2017/7/20 10:18	M1S 文件	1 KB
M930.m1s	2014/2/27 16:53	M1S 文件	1 KB
m933.m1s	2017/3/6 13:07	M1S 文件	1 KB
m999.m1s	2013/5/9 14:02	M1S 文件	1 KB
Mach3Mill	2017/7/20 10:15	XML 文档	150 KB
NcUsbPod.dll	2018/9/21 15:59	应用程序扩展	752 KB
Release Note-2.59.1	2018/9/21 11:27	文本文档	6 KB
slave home readme	2018/9/21 9:39	文本文档	1 KB
安装说明	2018/10/8 15:16	文本文档	1 KB
一键安装驱动(mach3必须在c盘)	2018/10/8 15:15	Windows 批处理...	1 KB

3.return to this interface, open file “中文资料”

English manual	2019-05-13 12:18	文件夹	
MACH3 Soft	2019-05-13 12:18	文件夹	
中文资料	2019-05-13 12:18	文件夹	
Mach1Lic	2008-08-25 12:13	DAT 文件	1 KB

Open “Mach3 界面” file, and open “六轴界面” file, copy “4zjm” file.

MACH3-界面	2019-05-13 12:18	文件夹	
macro宏代码	2019-05-13 12:18	文件夹	
MKX-V-5代卡接线图	2019-05-13 12:18	文件夹	
MKX-V-5代卡配置文件	2019-05-13 12:18	文件夹	
MKX-V-5代卡说明书(手轮说明书)	2019-05-13 12:18	文件夹	
XHC-MKX-V 驱动一键自动安装	2019-05-13 12:18	文件夹	
Mach3Mill	2019-04-28 14:34	XML 文档	151 KB
安装与使用说明	2018-12-12 16:07	文本文档	1 KB


六轴界面	2019-05-13 12:18	文件夹	
四轴界面	2019-05-13 12:18	文件夹	
六轴界面	2018-04-25 17:05	zip Archive	1,469 KB
四轴界面	2018-09-12 15:59	zip Archive	1,469 KB

4zjm	2019-05-13 12:18	文件夹	
XHC-6zjm.set	2016-10-27 14:23	SET 文件	71 KB
使用说明	2016-10-27 16:24	文本文档	1 KB

4.on the computer desk, right click “MACH3 Mill”, Click “attribute”, click File location



Find out file “Bitmaps”, Paste file”4zjm”in to it



5.return to this interface (中文资料/Mach3 界面/六轴界面), copy “XHC-6Zjm.set”,

名称	修改日期	类型	大小
4zjm	2019/5/10 17:52	文件夹	
XHC-6zjm.set	2016/10/27 14:23	SET 文件	71 KB
使用说明	2016/10/27 16:24	文本文档	1 KB

Paste it into WINXP(C :) mach3 as follow:

tools	2004-02-22 23:18	DAI 文件	10 KB
TurnJogIncs	2003-09-11 8:59	文本文档	1 KB
VideoOCX.ocx	2003-12-31 7:37	ActiveX 控件	448 KB
VideoOCXTools.ocx	2003-04-11 3:10	ActiveX 控件	68 KB
XHC-6zjm.set	2016-10-27 14:23	SET 文件	71 KB

6.find out “Mach3Mill “,copy it and paste into WINXP(C :) “mach3” file,it will show as follow

MACH3-界面	2019-05-13 12:18	文件夹	
macro宏代码	2019-05-13 12:18	文件夹	
MKX-V-5代卡接线图	2019-05-13 12:18	文件夹	
MKX-V-5代卡配置文件	2019-05-13 12:18	文件夹	
MKX-V-5代卡说明书 (手轮说明书)	2019-05-13 12:18	文件夹	
XHC-MKX-V 驱动一键自动安装	2019-05-13 12:18	文件夹	
Mach3Mill	2019-04-28 14:34	XML 文档	151 KB
安装与使用说明	2018-12-12 16:07	文本文档	1 KB


Mach1Lic	2008-08-25 12:13	DAT 文件	1 KB
Mach3	2004-10-13 1:47	BMP 文件	122 KB
Mach3	2012-10-13 3:08	应用程序	4,353 KB
Mach3	2011-04-20 20:59	安装信息	3 KB
Mach3.noapic	2010-05-02 22:30	NOAPIC 文件	107 KB
Mach3.sys	2011-04-12 1:14	系统文件	107 KB
Mach3Mill	2019-05-17 10:17	XML 文档	150 KB
Mach3MillGcode	2011-01-19 6:19	HTM 文件	89 KB

7.return to copy”Mach1lic”, and paste into WINXP(C :) “mach3” file


English manual	2019-05-13 12:18	文件夹	
MACH3 Soft	2019-05-13 12:18	文件夹	
中文资料	2019-05-13 12:18	文件夹	
Mach1Lic	2008-08-25 12:13	DAT 文件	1 KB

KeyGrabber	2005-05-16 21:46	应用程序	1,045 KB
KeyGrabberReadMe	2003-11-09 12:08	DOC 文档	16 KB
LastErrors	2019-05-17 10:17	文本文档	1 KB
LastFile	2005-01-16 3:43	文本文档	0 KB
LazyCamInstall	2008-01-04 6:17	应用程序	8,360 KB
LEDCodes	2006-05-05 0:52	文本文档	7 KB
Leds	2006-02-07 2:03	文本文档	1 KB
LegacyGreen	2006-05-04 10:00	BMP 文件	30 KB
LegacyRed	2006-05-04 10:00	BMP 文件	30 KB
LegacyRedGreen	2006-04-29 4:25	BMP 文件	30 KB
LegacyYellow	2006-05-04 10:00	BMP 文件	30 KB
Liability	2006-11-29 6:27	文本文档	2 KB
M3Plug	2006-07-09 11:45	应用程序	184 KB
m1076.m1s	2008-09-25 20:44	M1S 文件	11 KB
M1083.m1s	2008-03-06 11:45	M1S 文件	4 KB
Mach1Lic	2008-08-25 12:13	DAT 文件	1 KB
Mach3	2004-10-13 1:47	BMP 文件	122 KB


8:Open “machmill “software on computer desk, click “view”,it will show loadscreens



Choose loadscreens, find out “XHC-6z0jm.set”, and then open it.




It will show the page as follow, and then you can set the parameters




2、 A/B axis setting

1.A axis



2.B axis



Then all the setting is finished.

3、 Machine calibration

Calibration needs to use the calibration table


1. Use the calibration meter to move in the X-axis direction to ensure that the meter pointer jumps within 1~2 wires. as the picture shows;






Note: If it is not parallel, I hope you can use a soft thing to rap the 5-axis table to adjust the position, for example, with a wooden hammer, do not use hard things to hit the table or it will damage the 5-axis table.

2 Similarly, use the calibration meter to move in the X-axis direction to ensure that the meter pointer jumps within 1~2 filaments. as the picture shows;





If it is not parallel, you can rotate the angle of the A-axis table to adjust and keep it parallel.

3. Use the calibration meter to move in the Y-axis direction to ensure that the meter pointer jumps within 1~2 wires. as the picture shows;






4. If it is not parallel, you can rotate the angle of the B-axis table to adjust and keep it parallel

4、 Starting point setting

1. After calibration, only the X Y Z axis is set at the starting point. The B axis has zero at the calibration time. When the A axis is calibrated, the A axis does not need to set the starting point.




2. First, attach the centering rod to the spindle chuck. At the same time, the speed is 400 ~ 600s



Noted: the speed cannot be too high or it will damage the centering rod.

3. Y axis start point setting



Move the edge refiner to the front of the axis table and then move the zero Y axis to the other side. The Mach3 software displays the total edge finder's travel. The starting point of the Y axis is the intermediate point. Under normal circumstances, this number is 63. Finally, move the spindle to 63.000, zero Y-axis. Y-axis starting point has been completed





Divide the total stroke value by two, shake the Y-axis to "the value obtained by dividing by two" and click the Y-axis to clear.

4 .X axis start point setting,
It is the same as the Y-axis start point setting.



4. Z axis start point setting



5. The tool touches the direction indicated by the arrow, then click Z to clear, the Z-axis starting point is completed.